

**WEYAUWEGA AREA BLACKTOP PULL
MAIN STREET, WEYAUWEGA, WI
~~MAY 23, 2020~~ AUGUST 8, 2020
ANTIQUÉ AND FARM TRACTOR PULL
WEIGH INS: 8 A.M PULL STARTS: 10 A.M**

Registration open all day - \$20.00 per hook

Pure Stock Classes (1958 and Older): 3600, 4000, 4600, 5000, 5600, 6000, 6400, 7000, and 7600

Paced at 3.5 mph, 20" Drawbar

Max Tire Size: 3600, 4000 & 4600 = 14.9" x 38" = 200 sq. inches

5000, 5600 & 6000 = 16.9" x 28" = 209 sq. inches

6400, 7000 & 7600 = 16.9" x 38" = 252 sq. inches

Antique Classes (1958 and Older): 3500, 4200, 4700, 5300, 5900, 6500, and 7500

Paced at 4 mph, 20" Drawbar

Max Tire Size: 3500 – 4700 = 16.9" x 28" = 209 sq. inches

5300 & 5900 = 16.9" x 38" = 252 sq. inches

6500 & 7500 = 18.4" x 38" = 300 sq. inches

Open Antique Classes: 3750, 4250, 4750, 5750, 6750 and 7750

6750 and 7750 any tractor is eligible

Paced at 8 mph, 20" Drawbar

Max Tire Size: All classes = 18.4" x 38" = 300 sq. inches

Farm Classes (Any Age): 4800, 5800, 6800, 7800, 8800, 9850, 10300 and 10850

Paced at 10 mph, 20" Drawbar

No Tire Limits

100% Payback Classes: \$100.00 Guarantee 1st Place

1. Pure Stock – 5100 Maximum Tire 15.5" = 209 sq. inches Paced at 3.5 mph

2. Pure Stock – 6100 Maximum Tire 16.9" = 252 sq. inches Paced at 3.5 mph

2. Antique – 5700 Maximum Tire 16.9" = 252 sq. inches Paced at 4 mph

3. Any Tractor – 6700 Maximum Tire 18.4" = 300 sq. inches Paced at 8 mph

NOTE – ANYONE USING A TIRE SIZE OF 28" DIAMETER OR LOWER MAY USE A 16" WIDTH TIRE

For more information please call: Jerry Loehrke – (715) 347-8282 or Jeff Loehrke – (715) 281-4629.

GENERAL RULES FOR ALL PULLERS

1. All contestants enter at their own risk. SAFETY IS THE #1 PRIORITY OVER ALL RULES!!
2. Driver's age 12-16 years can only pull in Pure Stock and must have written permission from their parent or legal guardian, and must present their farm safety course certification. No one under the age of 12 may enter. Drivers must be 16 years of age or older in all other classes.
3. Driver must remain in tractor seat at all times, and operate the tractor in a safe manner at all times on and off the track. Think of the safety of yourself and others.
4. No John Deere G's, Massey 44, Farmall M, Minneapolis Moline U and U.B's shall enter any class below 5,000 lbs except in Open Antique.
5. Kill switches, wheelie bars, and fenders are required in Open Antique and recommended in Antique classes. Wheelie bars must be strong enough to hold tractor. We strongly recommend a pad size of at least 5". Side shields and safety blankets are also strongly recommended.
6. No pressurized fuel tanks allowed. LP gas tanks certified for LP gas only are allowed.
7. All tires must be on the tractor. Tires may be mounted forwards or backwards. No tracks, duals, or chains allowed.
8. All tractors must re-weigh and have hitch checked for height before hooking to eliminator. Nothing may be added or taken off the tractor after you are officially weighed-in.
9. If anything falls off the tractor before it is unhooked from the eliminator, the tractor will be disqualified.
10. The officials have the right to stop any entry at any time during the pull, and reserve the right to disqualify or deny entry at any time. The official's word is final.
11. Any tractor violating the track boundary will be measured from that distance if driver stops when flagged.
12. Tractors should be equipped with a 2½" clevis or pulling eye. Absolutely NO floating drawbars in any class at any time. Minimum length of drawbar from center of axle to point of hook is 18". All hitches must be solid in all directions. No bracing to drawbar behind rear cast of tractor above the point of hook.
13. No T.A. or Power Shifting except in farm classes.
14. IF HORN BLOWS AFTER DESIGNATED FOOTAGE ALL TRACTORS MUST STOP.
15. Unless there is a tie, there will only be one pull per tractor per class.
16. All drivers should be in line and ready to pull at the start of their weight class.
17. Official decisions made at the Driver's Meeting take priority over printed rules.
18. Classes may be added or subtracted on the day of the pull.

19. ANY PERSON CAUGHT TAMPERING WITH ANOTHER PULLER'S TRACTOR WILL BE BANNED FROM THE PULL.

ADDITIONAL RULES FOR PURE STOCK CLASSES

1. Age of tractor must be 1958 or older.
2. HP & RPM: No more than 20% over the factory HP or RPM according to the serial number of tractor and according to the Nebraska Test. Working PTO must be installed on the tractor, unaltered positive throttle stop, and working governor is mandatory.
3. Tractor must have stock model block, carburetor, and serial number for the make and model.
4. Tractors must run only on stock fuel designed for that tractor.
5. Weights should be fastened to tractor in any safe way, including weight brackets. No weights may be added in front of front casting or 24" behind the center of the rear axle.
6. Tractor must have original drawbar. No non-factory adjustable drawbars allowed.
7. All other general rules apply.

ADDITIONAL RULES FOR ANTIQUE CLASSES

1. Age of Tractor must be 1958 or older.
2. Weights may extend frontward, no more than 24" in front of the tractor casting and backward, no more than 24" behind center of rear axle. Weights should be safely fastened.
3. All other general rules apply.

ADDITIONAL RULES FOR OPEN ANTIQUE CLASSES

1. HP & RPM – Any horsepower is allowed. IF RPM exceeds twice original factory specifications, then safety equipment such as bell housing blanket or a flywheel wrap are highly recommended. Working governor and dead man's throttle are highly recommended. In the opinion of the track officials, any tractor operating unsafely will be disqualified.
2. Weights may extended frontward, no more than 24" in front of the tractor casting and backward, no more than 24" behind center of rear axle. Weights should be safely fastened.
3. No switching gears after the first 100 feet.
4. All other general rules apply.

ADDITIONAL RULES FOR FARM CLASSES

1. Tractor may be of any age.
2. Weights may extend frontward, no more than 24" in front of the tractor casting and any reasonable distance in the back. All weights must be safely and securely fastened. A 12" wide opening must be left for hooking chain to drawbar.
3. Tractors must hook off belly mount drawbar in stock location.

4. Wheelie bars, kill switches, and dead man throttles are highly recommended in all farm classes.
5. All other general rules apply.

100% PAYBACK CLASSES

1. Pure Stock – 5100 Maximum Tire 15.5” = 209 sq. inches Paced at 3.5 mph
2. Pure Stock – 6100 Maximum Tire 16.9” = 252 sq. inches Paced at 3.5 mph
3. Antique – 5700 Maximum Tire 16.9” = 252 sq. inches Paced at 4 mph
4. Any Tractor – 6700 Maximum Tire 18.4” = 300 sq. inches Paced at 8 mph
5. Payment will be 50% - 1st Place
 30% - 2nd Place
 20% - 3rd Place
6. Each Tractor may only enter one 100% payback class.
7. All rules pertain to each class.
8. TRACTOR MUST BE IN AT LEAST 2 OTHER CLASSES BEFORE IT CAN BE ELIGIBLE FOR 100% PAYBACK.